

Installing “HandHeld” wireless USB scanner.

- 1) Plug power cord in.
- 2) Plug your scanner into any USB port in your PC.
- 3) Scan the ‘USB Keyboard (PC)’ barcode on page 4 of your instruction book.
- 4) Scan the ‘Add CR Suffix’ barcode on page 8 of the same book.

Your scanner is now configured correctly and ready for use.

All settings have been saved to your scanner base, and will be saved, even if you connect the base to another PC.

This document was created with Win2PDF available at <http://www.daneprairie.com>.
The unregistered version of Win2PDF is for evaluation or non-commercial use only.